Original	Sustituto	Original	Sustituto
RECEIVER Power Receiver	Power	3 STEREO 3 Stereo	LANG I/II AUDIO Audio / Lang I/II
AUDIO Power Audio	NETFLIX SEARCH Red / Netflix / Search	TEST Test	GOTO TEXT Text / Goto
TV Power TV	Prime Video RANDOM Blue / Prime Video / Random	CH SELECT CH Select	OPT-TOOLS SETUP Setup / OPT /
VCR Power VCR	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	HELP Help	ANGLE INFO Info / Angle
VDP Power VDP	YouTube REPEAT A-B Yellow / YouTube / Repeat	DISC Disc	LIST SMART Smart / List
CD Power CD	APP REPEAT Green / APP / Repeat	DISC ENTER Disc Enter	MEDIA DISPLAY Display / Media
TAPE Power TAPE	SHIFT + APP REPEAT Shift + Green / APP /	TV/AV TV / AV	RDS AV INPUT AV / Input / RDS
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	1 TUNER 1	TV 1 1
CD CD	SHIFT + CD-STB 3 Shift + 3	2 TUNER 2	DVD 2 2
TAPE TAPE	SHIFT + TAPE 5 Shift + 5	3 TUNER 3	CD-STB 3 3
TV TV	SHIFT + TV 1 Shift + 1	DIRECT TUNING Direct Tuning	HOME MENU Menu / Home
VDP/ VDP 6CH VDP / VDP 6CH	SHIFT + DVD 2 Shift + 2	TV VOL+ TV Vol +	SHIFT + + VOL Shift + Vol +
VCR 1 VCR 1	SHIFT + VIDEO 4 Shift + 4	4 TUNER 4	VIDEO 4 4
VCR 2 VCR 2	SHIFT + AUX-HDD 7 Shift + 7	5 TUNER 5	TAPE 5 5
CH LEVEL − CH Level -	CH PAGE − CH- / Page-	6 TUNER 6	TUNER 6 6
CH LEVEL + CH Level +	+ CH PAGE CH+ / Page+	≥10/-/-- TUNER >=10	-/-- GUIDE EPG Guide / EPG / -/--
DOLBY PRO LOGIC SURROUND Surround	SURROUND Eject / Surround	TV VOL− TV Vol -	SHIFT + VOL − Shift + Vol -

Original		Sustituto	
7	TUNER 7	AUX - HDD 7	7
8	TUNER 8	USB 8	8
9	TUNER 9	BLUETOOTH 9	9
0	TUNER 0	HDMI - SAT 0	0
◀◀	TAPE <<	TUNE- ◀◀	<< / Tune-
▶▶	TAPE >>	TUNE+ ▶▶	>> / Tune+
DECK1/2	TAPE Deck 1/2	OK	OK
◀	TAPE Rev. Play	◀	Left
❚❚	TAPE Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze
■	TAPE Stop	HOLD ■	Stop / Hold
▶	TAPE Play	SLOW ▶	Play / Slow
▶	TAPE Play	▶	Right
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
VOLUME –	Volume-	VOL –	Vol -
VOLUME +	Volume+	+ VOL	Vol +

Original	Sustituto

Original	Sustituto	Original	Sustituto
RECEIVER Power Receiver	Power	3 STEREO 3 Stereo	LANG I/II AUDIO Audio / Lang I/II
AUDIO Power Audio	NETFLIX SEARCH Red / Netflix / Search	TEST Test	GOTO TEXT Text / Goto
TV Power TV	Prime Video RANDOM Blue / Prime Video / Random	CH SELECT CH Select	OPT-TOOLS SETUP Setup / OPT /
VCR Power VCR	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	HELP Help	ANGLE INFO Info / Angle
VDP Power VDP	YouTube REPEAT A-B Yellow / YouTube / Repeat	DISC Disc	LIST SMART Smart / List
CD Power CD	APP REPEAT Green / APP / Repeat	DISC ENTER Disc Enter	MEDIA DISPLAY Display / Media
TAPE Power TAPE	SHIFT + APP REPEAT Shift + Green / APP /	TV/AV TV / AV	RDS AV INPUT AV / Input / RDS
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	1 CD 1	TV 1 1
CD CD	SHIFT + CD-STB 3 Shift + 3	2 CD 2	DVD 2 2
TAPE TAPE	SHIFT + TAPE 5 Shift + 5	3 CD 3	CD-STB 3 3
TV TV	SHIFT + TV 1 Shift + 1	DIRECT TUNING Direct Tuning	HOME MENU Menu / Home
VDP/ VDP 6CH VDP / VDP 6CH	SHIFT + DVD 2 Shift + 2	TV VOL+ TV Vol +	SHIFT + + VOL Shift + Vol +
VCR 1 VCR1	SHIFT + VIDEO 4 Shift + 4	4 CD 4	VIDEO 4 4
VCR 2 VCR 2	SHIFT + AUX-HDD 7 Shift + 7	5 CD 5	TAPE 5 5
CH LEVEL − CH Level -	CH PAGE − CH- / Page-	6 CD 6	TUNER 6 6
CH LEVEL + CH Level +	+ CH PAGE CH+ / Page+	≥10/-/-- CD >=10	-/-- GUIDE EPG Guide / EPG / -/--
DOLBY PRO LOGIC SURROUND Surround	SURROUND Eject / Surround	TV VOL− TV Vol -	SHIFT + VOL − Shift + Vol -

Original		Sustituto	
7	CD 7	AUX - HDD 7	7
8	CD 8	USB 8	8
9	CD 9	BLUETOOTH 9	9
0	CD 0	HDMI - SAT 0	0
⏮	CD I <<	PRESET- ⏮	I << / Preset-
⏭	CD >>I	PRESET+ ⏭	>>I / Preset+
◀◀	CD <<	TUNE- ◀◀	<< / Tune-
▶▶	CD >>	TUNE+ ▶▶	>> / Tune+
⏸	CD Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
■	CD Stop	HOLD ■	Stop / Hold
▶	CD Play	SLOW ▶	Play / Slow
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
VOLUME −	Volume-	VOL −	Vol -
VOLUME +	Volume+	+ VOL	Vol +

Original	Sustituto

Original	Sustituto
Power Receiver	Power
Power Audio	Red / Netflix / Search
Power TV	Blue / Prime Video / Random
Power VCR	Shift + Red / Netflix /
Power VDP	Yellow / YouTube / Repeat
Power CD	Green / APP / Repeat
Power TAPE	Shift + Green / APP /
TUNER	Shift + 6
CD	Shift + 3
TAPE	Shift + 5
TV	Shift + 1
VDP / VDP 6CH	Shift + 2
VCR1	Shift + 4
VCR 2	Shift + 7
CH Level -	CH- / Page-
CH Level +	CH+ / Page+
Surround	Eject / Surround

Original	Sustituto
3 Stereo	Audio / Lang I/II
Test	Text / Goto
CH Select	Setup / OPT /
Help	Info / Angle
Disc	Smart / List
Disc Enter	Display / Media
TV / AV	AV / Input / RDS
VDP 1	1
VDP 2	2
VDP 3	3
Direct Tuning	Menu / Home
TV Vol +	Shift + Vol +
VDP 4	4
VDP 5	5
VDP 6	6
VDP >=10	Guide / EPG / -/--
TV Vol -	Shift + Vol -

Original		Sustituto	
	VDP 7		7
	VDP 8		8
	VDP 9		9
	VDP 0		0
	VDP I <<		I << / Preset-
	VDP >>I		>>I / Preset+
	VDP <<		<< / Tune-
	VDP >>		>> / Tune+
	VDP Pause		Pause / Step / Freeze
	VDP Stop		Stop / Hold
	VDP Play		Play / Slow
	Muting		Mute / Dimmer
	Volume-		Vol -
	Volume+		Vol +

Original	Sustituto

Original	Sustituto	Original	Sustituto
RECEIVER Power Receiver	Power	3 STEREO 3 Stereo	LANG I/II AUDIO Audio / Lang I/II
AUDIO Power Audio	NETFLIX SEARCH Red / Netflix / Search	TEST Test	GOTO TEXT Text / Goto
TV Power TV	Prime Video RANDOM Blue / Prime Video / Random	CH SELECT CH Select	OPT-TOOLS SETUP Setup / OPT /
VCR Power VCR	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	HELP Help	ANGLE INFO Info / Angle
VDP Power VDP	YouTube REPEAT A-B Yellow / YouTube / Repeat	DISC Disc	LIST SMART Smart / List
CD Power CD	APP REPEAT Green / APP / Repeat	DISC ENTER Disc Enter	MEDIA DISPLAY Display / Media
TAPE Power TAPE	SHIFT + APP REPEAT Shift + Green / APP /	TV/AV TV / AV	RDS AV INPUT AV / Input / RDS
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	1 VCR 1 1	TV 1 1
CD CD	SHIFT + CD-STB 3 Shift + 3	2 VCR 1 2	DVD 2 2
TAPE TAPE	SHIFT + TAPE 5 Shift + 5	3 VCR 1 3	CD-STB 3 3
TV TV	SHIFT + TV 1 Shift + 1	DIRECT TUNING Direct Tuning	HOME MENU Menu / Home
VDP/ VDP 6CH VDP / VDP 6CH	SHIFT + DVD 2 Shift + 2	TV VOL+ TV Vol +	SHIFT + + VOL Shift + Vol +
VCR 1 VCR1	SHIFT + VIDEO 4 Shift + 4	4 VCR 1 4	VIDEO 4 4
VCR 2 VCR 2	SHIFT + AUX-HDD 7 Shift + 7	5 VCR 1 5	TAPE 5 5
CH LEVEL − CH Level -	CH PAGE − CH- / Page-	6 VCR 1 6	TUNER 6 6
CH LEVEL + CH Level +	+ CH PAGE CH+ / Page+	≥10/-/-- VCR 1 >=10	-/-- GUIDE EPG Guide / EPG / -/--
SURROUND Surround	SURROUND Eject / Surround	TV VOL− TV Vol -	SHIFT + VOL − Shift + Vol -

Original		Sustituto	
7	VCR 1 7	AUX - HDD 7	7
8	VCR 1 8	USB 8	8
9	VCR 1 9	BLUETOOTH 9	9
0	VCR 1 0	HDMI - SAT 0	0
◀◀	VCR 1 <<	TUNE- ◀◀	<< / Tune-
▶▶	VCR 1 >>	TUNE+ ▶▶	>> / Tune+
II	VCR 1 Pause	STEP - FREEZE II	Pause / Step / Freeze
■	VCR 1 Stop	HOLD ■	Stop / Hold
▶	VCR 1 Play	SLOW ▶	Play / Slow
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
VOLUME –	Volume-	VOL –	Vol -
VOLUME +	Volume+	+ VOL	Vol +

Original	Sustituto