Original		Sustituto	
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Back		Back
	Menu		Menu
	Exit		Exit
	Up		Up

Original		Sustituto	
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	EPG		Guide
	TV/Radio		TV/R
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Rec		Rec
	Fav		Pre Ch
	Stop		Stop
	Media		Media
	I<<		I<<
	>>I		>>I
	>>		>>

Original		Sustituto	
	<<		<<
	Play	PLAY MODE	Play
	Pause		Pause
TTX	TTX	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
USB	USB	HOME SMART	Smart
TIMER	Timer	TIMER AV	AV

Original	Sustituto