Original		Sustituto	
TV/VIDEO	Tv/Video	PROGRAM TV/RADIO	TV/Radio /
I.SELECT	I.Select	LIST SMART	Smart / List
ON/STANDBY	On/Standby		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
CH/TRK	CH/TRK+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH/TRK	CH/TRK-	CH PAGE –	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
→	→		Right
DISPLAY	Display	MEDIA DISPLAY	Display / Media
0	0	HDMI-SAT 0	0

Original		Sustituto	
OSP	OSP	ANGLE INFO	Info / Angle
SHIFT/PIC.	←		Left
REC	Rec	REC MODE	Rec / Rec Mode
TIMER	Timer	TIMER SLEEP	Sleep / Timer
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REW	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
FF	>>	TUNE+	>> / Tune+
SLOW	I>/Slow	SHIFT + SLOW	Shift + Play /
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
INDEX –	Index-		Down
INDEX +	Index+		Up
C.RESET	C.Reset	RETURN BACK	Back / Return
COUNTER	Counter	SIZE ZOOM	Zoom / Size
SP/LP	SP/LP	FORMAT PICTURE	Picture / Format
	A3	Prime Video RANDOM	Blue / Prime Video / Random

Original	Sustituto
B1	Red / Netflix / Search
B2	Green / APP / Repeat
B3	Yellow / YouTube / Repeat

Original	Sustituto