Original	Sustituto	Original	Sustituto
Power	Power	Menu	Menu / Home
Mute	Mute / Dimmer	Up	Up
Play	Play / Slow	i	Info / Angle
Pause	Pause / Step / Freeze	Left	Left
Stop	Stop / Hold	OK	OK
Rec	Rec / Rec Mode	Right	Right
<<	<< / Tune-	Exit	Exit / Cancel / Clear
>>	>> / Tune+	Down	Down
Lang	Audio / Lang I/II	Back	Back / Return
Source (Games)	Eject / Surround	Vol +	Vol +
Movie-Music-Phot	Picture / Format	World (Violet)	Smart / List
[≡] . .	Zoom / Size	PR+	CH+ / Page+
*/O	Sleep / Timer	Vol -	Vol -
TV	TV/Radio /	*/Q	Display / Media
Q.Menu	D.Menu / Top	PR-	CH- / Page-
[-O-]	Setup / OPT /	1	1
[≡] / Text	Text / Goto	2	2

Original		Sustituto		Original	Sustituto
3 def	3	CD - STB 3	3		
4 ghi	4	VIDEO 4	4		
5 jkl	5	TAPE 5	5		
6 mno	6	TUNER 6	6		
7 pqrs	7	AUX - HDD 7	7		
8 tuv	8	USB 8	8		
9 wxyz	9	BLUETOOTH 9	9		
Guide	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
Red	Red	NETFLIX SEARCH	Red / Netflix / Search		
Green	Green	APP REPEAT	Green / APP / Repeat		
Yellow	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
Blue	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
Recall	Recall	SHIFT + RETURN BACK	Shift + Back / Return		