Original		Sustituto	
POWER	Power		Power
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
SKI	I<< Skip	PRESET-	I<< / Preset-
KIP	Skip >>I	PRESET+	>>I / Preset+
SLOW /S	<< Slow/Search	TUNE-	<< / Tune-
/SEARCH	Slow/Search >>	TUNE+	>> / Tune+
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Down		Down

Original		Sustituto	
RETURN	Return	RETURN BACK	Back / Return
PLAY MODE	Play Mode	NETFLIX SEARCH	Red / Netflix / Search
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ANGLE	Angle	ANGLE INFO	Info / Angle
REPEAT MODE	Repeat Mode	APP REPEAT	Green / APP / Repeat
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
A-B REPEAT	A-B Repeat	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
V.S.S.	V.S.S.	LIST SMART	Smart / List
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Sustituto		Original	Sustituto
SETUP	Set up	OPT-TOOLS SETUP	Set up / OPT /		
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
0	0	HDMI - SAT 0	0		
≧10	>10	-/-- GUIDE EPG	Guide / EPG / -/--		