Original		Sustituto	
	Power		Power
ECO	Eco	PC FAV MARKER	Fav / Marker / PC
NET	Net	MEDIA DISPLAY	Display / Media
1	Net Radio 1	TV 1	1
2	Net Radio 2	DVD 2	2
3	Net Radio 3	CD - STB 3	3
HDMI1	HDMI1	VIDEO 4	4
HDMI2	HDMI2	TAPE 5	5
	Bluetooth	SHIFT + BLUETOOTH 9	Shift + 9
HDMI3	HDMI3	AUX - HDD 7	7
HDMI4	HDMI4	USB 8	8
OPTICAL	Optical	BLUETOOTH 9	9
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
AUX 1	AUX1	-/-- GUIDE EPG	Guide / EPG / -/--
AUX 2	AUX2	HDMI - SAT 0	0
1	System Memory	SHIFT + TV 1	Shift + 1
2	System Memory	SHIFT + DVD 2	Shift + 2

Original		Sustituto	
3	System Memory	SHIFT + CD - STB 3	Shift + 3
SUB +	Sub+	CH PAGE +	CH+ / Page+
SUB −	Sub-	CH PAGE −	CH- / Page-
DIALOG LIFT	Dialog Lift	LIST SMART	Smart / List
VOL +	Vol+	VOL +	Vol+
VOL −	Vol-	VOL −	Vol-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
RETURN	Return	RETURN BACK	Back / Return
INFO	Info	ANGLE INFO	Info / Angle
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	OK
MOVIE	Movie	NETFLIX SEARCH	Red / Netflix / Search

Original	Sustituto	Original	Sustituto
Music	Green / APP / Repeat		
Entertainment	Yellow / YouTube / Repeat		
Off	Blue / Prime Video / Random		
3D Surround	Audio / Lang I/II		
Surround	Eject / Surround		
Stereo	Sound / Title		
Target	Picture / Format		
Clear Voice	Exit / Cancel / Clear		
Enhancer	Zoom / Size		
Connect	Text / Goto		
WPS/CH Level	Subtitle / EQ		