Original	Sustituto	Original	Sustituto
Power	Power	Clear	Exit / Cancel / Clear
Open/Close	Eject / Surround	2nd Audio	Mute / Dimmer
Enter	OK	Stop	Stop / Hold
Up	Up	Search	Shift + Red / Netflix /
Down	Down	Pause	Pause / Step / Freeze
Right	Right	Play	Play / Slow
Left	Left	<<	<< / Tune-
Audio	Audio / Lang I/II	>>	>> / Tune+
Subtitle	Subtitle / EQ	I <<	I << / Preset-
PIP	Zoom / Size	>>I	>>I / Preset+
Top Menu	D. Menu / Top	Green/Program	Green / APP / Repeat
Pop-Up/Menu	Menu / Home	Red/Zoom	Red / Netflix / Search
Return	Back / Return	Yellow/Shuffle	Yellow / YouTube / Repeat
Home	Shift + Menu /	Blue/Repeat	Blue / Prime Video / Random
Miracast	Smart / List	1	1
On Screen	Display / Media	2	2
Status	Setup / OPT /	3	3

Tools

Original		Sustituto		Original	Sustituto
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		