Mandis shop

bomaker Njord I

Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
BT	BT	BLUETOOTH 9	9
BT	BT	TV 1	1
OPTICAL	OPTICAL	DVD 2	2
COAX	COAX	CD - STB 3	3
AUX/USB	AUX/USB	AUX - HDD 7	7
AUX/USB	AUX/USB	USB 8	8
AUX/USB	AUX/USB	VIDEO 4	4
+	+	+ VOL	Vol+
I<<	I<<	PRESET-	I<< / Preset-
I<<	I<<	TUNE-	<< / Tune-
Play/Pause	Play/Pause	SLOW	Play / Slow
Play/Pause	Play/Pause	STEP - FREEZE	Pause / Step / Freeze
Play/Pause	Play/Pause	OK	OK
>>I	>>I	PRESET+	>>I / Preset+
>>I	>>I	TUNE+	>> / Tune+

Original		Sustituto	
	-	VOL −	Vol-
GENERAL	General	HOME MENU	Menu / Home
VOICE	Voice	ANGLE INFO	Info / Angle
3D/RESET	3D/Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
BASS	Bass	LIST SMART	Smart / List
BASS+	Bass+		Right
BASS-	Bass-		Left
TREBLE	Treble	MEDIA DISPLAY	Display / Media
TREBLE+	Treble+		Up
TREBLE-	Treble-		Down

https://mandos-a-distancia.es/es/bomaker/1067138-96873-mando-de-sustitucion-para-bomaker-Njord-I.html