



| Original | Sustituto |
|---|--|
|  |  Power |
|  |  Mute |
|  |  Format |
|  |  Dual |
|  |  3D |
|  |  Smart |
|  |  Play |
|  |  Pause |
|  |  Stop |
|  |  AV |
|  |  Media |
|  |  TV/R |
|  |  1 |
|  |  2 |
|  |  3 |
|  |  4 |
|  |  5 |

| Original | Sustituto |
|---|---|
|  |  6 |
|  |  7 |
|  |  8 |
|  |  9 |
|  |  0 |
|  |  Eject |
|  |  Pre Ch |
|  |  Back |
|  |  Ch - |
|  |  Ch + |
|  |  Vol - |
|  |  Vol + |
|  |  Up |
|  |  Right |
|  |  Down |
|  |  Left |
|  |  Ok |





| Original | Sustituto | Original | Sustituto |
|---|---|----------|-----------|
|  |  Info | | |
|  |  Menu | | |
|  |  Options | | |
|  |  D. Menu | | |
|  |  Subt | | |
|  |  Red | | |
|  |  Green | | |
|  |  Yellow | | |
|  |  Blue | | |
|  |  Text | | |
|  |  Exit | | |
|  |  Guide | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Sustituto |
|----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

