







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Exit/Back	 Exit
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 P+	 Ch +
 6	 6	 P-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 [<<]	 Format
 0	 0	 TV/R	 TV/R
 Recall	 Pre Ch	 [i+] / [≡i]	 Info
 Source	 AV	 Text / [≡] / [≡] []	 Text
 Menu/DVD	 Menu	 Pause	 Pause
 Guide	 Guide	 Play	 Play
 [] [] [] []	 3D	 Dual	 Dual






















































































Original	Sustituto
 <<< / [≡>]	 <<<
 <<< / [≡>]	 SETTINGS  OPT Options
 SUBTITLE >>> / Subtitle	 AD  SUBT Subt
 SUBTITLE >>> / Subtitle	 >>>
 >	 HOME  SMART Smart
 >>> / [≡>]	 Stop
 >>> / [≡>]	 ZOOM  Eject
 >>> / [≡>]	 I<<<
 >>> / [⊕][≡>]	 >>>I
 >>> / [⊕][≡>]	 RETURN  BACK Back
 Red	 A Red
 Green	 B Green
 Yellow	 C Yellow
 Blue	 D Blue

Original	Sustituto












































Original	Sustituto	Original	Sustituto
 Power	 Power	 Right	 Right
 Mute	 Mute	 Down	 Down
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	  / [v]	 Pause
 4	 4	  / I/II	 Play
 5	 5	  / I/II	 Dual
 6	 6	  / [≡●]	 <<<
 7	 7	  / [≡●]	 TV/R
 8	 8	  / Subtitle	 >>>
 9	 9	  / Subtitle	 Subt
 0	 0	  ▲	 Smart
 _ Menu/DVD	 TOP MENU MENU Menu	  / [≡□]	 Stop
 - Exit/Back	 CLEAR EXIT Exit	  / [≡⇅]	 Eject
 - Up	 Up	  / [≡⇅]	 I<<<
 Left	 Left	  / [⊙][≡X]	 >>>I
 OK	 OK	  / [⊙][≡X]	 Back





Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Source	 AV
 P+	 Ch +
 P-	 Ch -
 Vol-	 Vol -
 Vol+	 Vol +

Original	Sustituto
  / [v]	 Pause
 / I/II	 Play
 / I/II	 Dual
 / [≡●]	 <<<
 / [≡●]	 TV/R
 / Subtitle	 >>>
 / Subtitle	 Subt
 ▲	 Smart
 / [≡□]	 Stop
 / [≡⇅]	 Eject
 / [≡⇅]	 I<<<
 / [⊙][=X]	 Back
 / [⊙][=X]	 >>>I

