


Original	Sustituto
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
FAV	Pre Ch
SUB	Subt
Menu	Menu
EPG	Guide
Info	Info

Original	Sustituto
Exit	Exit
Up / CH+	Up
Up / CH+	Ch +
Down / CH-	Down
Down / CH-	Ch -
Left	Left
OK	Ok
Right	Right
Vol+	Vol +
Vol-	Vol -
ALT / <<	Smart
ALT / <<	<<
List / >>	List
List / >>	>>
Red / I<< / Lang	Red
Red / I<< / Lang	I<<
Red / I<< / Lang	Dual





Original	Sustituto
Blue / >>I / Text	Blue
Blue / >>I / Text	>>I
Blue / >>I / Text	Text
Green / Audio	Green
Green / Audio	Shift + Dual
Yellow / Pause	Yellow
Yellow / Pause	Pause
Zoom	Eject
Play / TV/Radio	TV/R
Play / TV/Radio	Play
Media / DTV	Media
Auto Scan	Options

Original	Sustituto

