



























































Original	Sustituto	Original	Sustituto
 Power	 Power	 TV / AV	 AV
 Mute	 Mute	 Red / Audio	 Red
 1	 1	 Red / Audio	 Dual
 2	 2	 Green / Text	 Green
 3	 3	 Green / Text	 Text
 4	 4	 Yellow / [ _ ]	 Yellow
 5	 5	 Yellow / [ _ ]	 Subt
 6	 6	 Blue / Timer	 Blue
 7	 7	 Blue / Timer	 Shift + AV
 8	 8	 EPG	 Guide
 9	 9	 Menu	 Menu
 0	 0	 Info	 Info
 TV / Radio	 TV/R	 Exit	 Exit
 ←PR	 Back	 Up / PR+	 Up
 ↑	 >>I	 Up / PR+	 Ch +
 ↓	 I<<	 Down / PR-	 Down
 Pause	 Pause	 Down / PR-	 Ch -





Original	Sustituto	Original	Sustituto
Right / Vol+	Right		
Right / Vol+	Vol +		
Left / Vol-	Left		
Left / Vol-	Vol -		
OK / List	Ok		
OK / List	List		
FAV	Pre Ch		
Sleep	Sleep		
Smart	Smart		
PAL / NTSC	Format		

