










































































































| Original | Sustituto |
|--|--|
|  Power |  Power |
|  Sleep |  Sleep / Timer |
|  Screen |  Picture / Format |
|  Presets |  Setup / OPT / |
|  ↔ |  TV/Radio / |
|  FAV |  Shift + Fav / Marker / PC |
|  Lang |  Audio / Lang I/II |
|  Subtitle |  Subtitle / EQ |
|  TXT |  Text / Goto |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |

| Original | Sustituto |
|---|---|
|  9 |  9 |
|  EPG |  Guide / EPG / -/- |
|  0 |  0 |
|  Swap |  Fav / Marker / PC |
|  |  D.Menu / Top |
|  |  Smart / List |
|  Source |  AV / Input / RDS |
|  Menu |  Menu / Home |
|  |  |
|  |  |
|  OK |  OK |
|  |  |
|  |  |
|  C |  Exit / Cancel / Clear |
|  Disp. |  Display / Media |
|  |  Shift + Red / Netflix / |
|  |  Back / Return |





| Original | Sustituto |
|--|--|
|  CH+ |  CH+ / Page+ |
|  Info |  Info / Angle |
|  Vol+ |  Vol+ |
|  CH- |  CH- / Page- |
|  Mute |  Mute / Dimmer |
|  Vol- |  Vol- |
|  Rec |  Rec / Rec Mode |
|  Pause |  Pause / Step / Freeze |
|  I<< |  I<< / Preset- |
|  >>I |  >>I / Preset+ |
|  << |  << / Tune- |
|  Play |  Play / Slow |
|  Stop |  Stop / Hold |
|  >> |  >> / Tune+ |
|  Red/↑/Zoom |  Red / Netflix / Search |
|  Red/↑/Zoom |  Zoom / Size |
|  Green/↓/Repeat |  Green / APP / Repeat |

| Original | Sustituto |
|---|---|
|  Yellow/Root |  Yellow / YouTube / Repeat |
|  Blue/Title |  Blue / Prime Video / Random |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

