





| Original                                                                            | Substitut | Original                                                                            | Substitut        |
|-------------------------------------------------------------------------------------|-----------|-------------------------------------------------------------------------------------|------------------|
|    | Power     |    | Power            |
|    | Mute      |    | Mute / Dimmer    |
|    | 1         |    | 1                |
|    | 2         |    | 2                |
|    | 3         |    | 3                |
|    | 4         |    | 4                |
|    | 5         |    | 5                |
|    | 6         |    | 6                |
|    | 7         |    | 7                |
|   | 8         |   | 8                |
|  | 9         |  | 9                |
|  | 0         |  | 0                |
|  | DTV/ATV   |  | D.Menu / Top     |
|  | Recall    |  | Back / Return    |
|  | P.Mode    |  | Picture / Format |
|  | S.Mode    |  | Sound / Title    |
|  | Sleep     |  | Sleep / Timer    |

| Original                                                                              | Substitut | Original                                                                              | Substitut             |
|---------------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------|-----------------------|
|    | Menu      |    | Menu / Home           |
|    | Source    |    | AV / Input / RDS      |
|    | Up        |    | Up                    |
|    | Left      |    | Left                  |
|    | Enter     |    | OK                    |
|    | Right     |    | Right                 |
|    | Down      |    | Down                  |
|    | Exit      |    | Exit / Cancel / Clear |
|    | Display   |    | Display / Media       |
|   | Vol+      |   | Vol+                  |
|  | Vol-      |  | Vol-                  |
|  | MTS       |  | Info / Angle          |
|  | Rec List  |  | Smart / List          |
|  | CH+       |  | CH+ / Page+           |
|  | CH-       |  | CH- / Page-           |
|  | FAV/List  |  | Fav / Marker / PC     |
|  | Rec       |  | Rec / Rec Mode        |









| Original                                                                            |                        | Substitut                                                                           |                               | Original                                                                            |        | Substitut                                                                           |                             |
|-------------------------------------------------------------------------------------|------------------------|-------------------------------------------------------------------------------------|-------------------------------|-------------------------------------------------------------------------------------|--------|-------------------------------------------------------------------------------------|-----------------------------|
|    | Freeze                 |    | Pause / Step / Freeze         |  | Green  |  | Green / APP / Repeat        |
|    | Guide                  |    | Guide / EPG / -/-             |  | Yellow |  | Yellow / YouTube / Repeat   |
|    | <<                     |    | << / Tune-                    |  | Cyan   |  | Blue / Prime Video / Random |
|    | >> / Aspect            |    | >> / Tune+                    |                                                                                     |        |                                                                                     |                             |
|    | >> / Aspect            |    | Shift + Picture / Format      |                                                                                     |        |                                                                                     |                             |
|    | I<< / Cancel           |    | I<< / Preset-                 |                                                                                     |        |                                                                                     |                             |
|    | I<< / Cancel           |    | Shift + Exit / Cancel / Clear |                                                                                     |        |                                                                                     |                             |
|    | >>I / Sub.PG           |    | >>I / Preset+                 |                                                                                     |        |                                                                                     |                             |
|    | Stop / Index           |    | Stop / Hold                   |                                                                                     |        |                                                                                     |                             |
|    | Play/Pause / Timeshift |    | Play / Slow                   |                                                                                     |        |                                                                                     |                             |
|   | Tv/Radio               |   | TV/Radio /                    |                                                                                     |        |                                                                                     |                             |
|  | Subtitle               |  | Subtitle / EQ                 |                                                                                     |        |                                                                                     |                             |
|  | Reveal                 |  | Eject / Surround              |                                                                                     |        |                                                                                     |                             |
|  | Size                   |  | Zoom / Size                   |                                                                                     |        |                                                                                     |                             |
|  | Hold                   |  | Shift + Stop /                |                                                                                     |        |                                                                                     |                             |
|  | Text                   |  | Text / Goto                   |                                                                                     |        |                                                                                     |                             |
|  | Red                    |  | Red / Netflix / Search        |                                                                                     |        |                                                                                     |                             |





| Original                                                                            | Substitut |
|-------------------------------------------------------------------------------------|-----------|
|    | Power     |
|    | Mute      |
|    | 1         |
|    | 2         |
|    | 3         |
|    | 4         |
|    | 5         |
|    | 6         |
|    | 7         |
|    | 8         |
|  | 9         |
|  | 0         |
|  | DTV/ATV   |
|  | Recall    |
|  | P.Mode    |
|  | S.Mode    |
|  | Sleep     |

| Original                                                                              | Substitut |
|---------------------------------------------------------------------------------------|-----------|
|    | Menu      |
|    | Source    |
|    | Up        |
|    | Left      |
|    | Enter     |
|    | Right     |
|    | Down      |
|    | Exit      |
|    | Display   |
|    | Vol+      |
|  | Vol-      |
|  | MTS       |
|  | Rec List  |
|  | CH+       |
|  | CH-       |
|  | FAV/List  |
|  | Rec       |





| Original                                                                                                 | Substitut                                                                                                       | Original                                                                                   | Substitut                                                                                                       |
|----------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|  Freeze                 |  Pause / Step / Freeze         |  Green  |  Green / APP / Repeat        |
|  Guide                  |  Guide / EPG / -/-             |  Yellow |  Yellow / YouTube / Repeat   |
|  <<                     |  << / Tune-                    |  Cyan   |  Blue / Prime Video / Random |
|  >> / Aspect            |  >> / Tune+                    |                                                                                            |                                                                                                                 |
|  >> / Aspect            |  Shift + Picture / Format      |                                                                                            |                                                                                                                 |
|   << / Cancel           |   << / Preset-                 |                                                                                            |                                                                                                                 |
|   << / Cancel           |  Shift + Exit / Cancel / Clear |                                                                                            |                                                                                                                 |
|  >>  / Sub.PG           |  >>  / Preset+                 |                                                                                            |                                                                                                                 |
|  Stop / Index           |  Stop / Hold                   |                                                                                            |                                                                                                                 |
|  Play/Pause / Timeshift |  Play / Slow                   |                                                                                            |                                                                                                                 |
|  Tv/Radio              |  TV/Radio /                   |                                                                                            |                                                                                                                 |
|  Subtitle             |  Subtitle / EQ               |                                                                                            |                                                                                                                 |
|  Reveal               |  Eject / Surround            |                                                                                            |                                                                                                                 |
|  Size                 |  Zoom / Size                 |                                                                                            |                                                                                                                 |
|  Hold                 |  Shift + Stop /              |                                                                                            |                                                                                                                 |
|  Text                 |  Text / Goto                 |                                                                                            |                                                                                                                 |
|  Red                  |  Red / Netflix / Search      |                                                                                            |                                                                                                                 |

