






































































Original	Substitut
 Power	 Power
 Sleep	 Sleep / Timer
 Screen	 Picture / Format
 Presets	 Setup / OPT /
 ↔	 TV/Radio /
 FAV	 Shift + Fav / Marker / PC
 Lang	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 TXT	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Substitut
 9	 9
 EPG	 Guide / EPG / -/-
 0	 0
 Swap	 Fav / Marker / PC
	 D.Menu / Top
	 Smart / List
 Source	 AV / Input / RDS
 Menu	 Menu / Home
	 Up
	 Left
 OK	 OK
	 Right
	 Down
 C	 Exit / Cancel / Clear
 Disp.	 Display / Media
	 Shift + Red / Netflix /
	 Back / Return





Original	Substitut	Original	Substitut
	CH+		Yellow/Root
	Info		Blue/Title
	Vol+		
	CH-		
	Mute		
	Vol-		
	Rec		
	Pause		
	I<<		
	>>I		
	<<		
	Play		
	Stop		
	>>		
	Red/↑/Zoom		
	Red/↑/Zoom		
	Green/↓/Repeat		
			CH+ / Page+
			Info / Angle
			Vol+
			CH- / Page-
			Mute / Dimmer
			Vol-
			Rec / Rec Mode
			Pause / Step / Freeze
			I<< / Preset-
			>>I / Preset+
			<< / Tune-
			Play / Slow
			Stop / Hold
			>> / Tune+
			Red / Netflix / Search
			Zoom / Size
			Green / APP / Repeat
			Yellow / YouTube / Repeat
			Blue / Prime Video / Random

