

































































Original	Substitut	Original	Substitut
 Power	 Power	 0	 0
 Tv/Radio	 TV/R	 -/--	 Shift + Guide
 I/II/Auto	 3D	 Recall/Last View	 Back
 Mute	 Mute	 Sleep	 Sleep
 EPG	 Guide	 Source	 AV
 FAV	 Pre Ch	 Exit	 Exit
 Audio	 Dual	 Menu	 Menu
 Subtitle	 Subt	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 Enter	 Ok
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 P.Mode	 Shift + Format
 8	 8	 S.Mode	 Shift + Dual
 9	 9	 Aspect	 Format





	Original	Substitut	Original	Substitut
	Display	Info	Green	Green
	CH+	Ch +	Yellow	Yellow
	CH-	Ch -	Blue	Blue
	Text	Text	D.Menu	D. Menu
	Index	Media	Setup	Options
	Rec	Rec	D.Disp	Smart
	Pause	Pause		
	Play	Play		
	Stop	Stop		
	<</Hold	<<		
	>>/Subpage	>>		
	I<</Size	I<<		
	>>I/Cancel	>>I		
	Eject	Eject		
	A-B/Mix	List		
	Repeat/Reveal	+  Shift + Text		
	Red	Red		

