



Original		Substitut		Original		Substitut	
	Power		Power				
	Back		Back				
	Home		Smart				
	Up		Up				
	Down		Down				
	Left		Left				
	Right		Right				
	OK		Ok				
	Info/Menu		Menu				
	Play/Pause		Play				
	Stop		Stop				
	I<</<<		<<				
	>>I/>>		Ch -				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

