





















































Original	Substitut
	Mute
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Swap
	0
	AV
	[]
	♪
	[<>]

Original	Substitut
	Mute / Dimmer
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Setup / OPT /
	0
	AV / Input / RDS
	Shift + 1
	Sound / Title
	Picture / Format

Original	Substitut
	[i]
	Up
	Left
	OK
	Right
	Down
	Red
	Green
	Yellow
	Blue
	Vol+
	Text
	Menu
	CH+
	Vol-
	Back
	Tv/Exit

Original	Substitut
	Info / Angle
	Up
	Left
	OK
	Right
	Down
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Vol+
	Text / Goto
	Menu / Home
	CH+ / Page+
	Vol-
	Back / Return
	TV/Radio /



Original

Substitut

Original

Substitut

	CH-		CH- / Page-
	FAV		Fav / Marker / PC
	Subtitle		Subtitle / EQ
	Audio		Audio / Lang I/II
	Guide		Guide / EPG / -/--
	[?]		Shift + Info / Angle
	[≡x]		Shift + 5
	[:]≡]		Shift + 4
	[↕]		Shift + 3
	[↕]		Shift + 2
	PIP Pos		D.Menu / Top
	PIP Size		Zoom / Size
	PIP		Eject / Surround

