





	Original	Substitut	Original	Substitut
	Power			Ok
	Aspect			AV
	Off Timer			Back
	Auto Setup			Media
	Pos./Size			Pre Ch
	[]/Picture			Guide
	J/Sound			Eject
	Set Up			
	Mute			
	Vol+			
	Vol-			
	N			
	R			
	Up			
	Down			
	Right			
	Left			

