







































































Original	Substitut	Original	Substitut
 Power	 Power	 Exit	 Exit
 Mute	 Mute	 Up	 Up
 DVD Setup	 Media	 Down	 Down
 Title	 List	 Right	 Right
 Menu (Blue)	 D. Menu	 Left	 Left
 USB/CR	 3D	 Enter	 Ok
 Nicam/A2	 Shift + Options	 1	 1
 Sleep	 Sleep	 2	 2
 Aspect	 Format	 3	 3
 Eject	 Eject	 4	 4
 Display	 Shift + Info	 5	 5
 Auto	 Back	 6	 6
 P.Mode	 Shift + Format	 7	 7
 S.Mode	 Shift + Dual	 8	 8
 DTV	 Smart	 9	 9
 Source	 AV	 0	 0
 Menu	 Menu	 -/--	 Shift + Guide





Original		Substitut		Original		Substitut	
	EPG		Guide		I<</Reveal		I<<
	Recall		Pre Ch		>>I/Sbpage		>>I
	CH+		Ch +		Subtitle (Green)		Subt
	CH-		Ch -		Zoom		Shift + Eject
	Info		Info		Goto		Options
	FAV		Shift + Pre Ch		Subtitle (Blue)		Shift + Subt
	Tv/Radio		TV/R		Angle		Shift + TV/R
	Audio		Dual		Red/Program		Red
	Vol+		Vol +		Green/Intro		Green
	Vol-		Vol -		Yellow/Repeat		Yellow
	Text		Text		Blue/A-B		Blue
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec/Hold		Rec				
	<</Index		<<				
	>>/Size		>>				

