



Original	Substitut
	Power
	Red
	Green
	Yellow
	Blue
	PopUp Menu/Disc Menu
	Home
	Top Menu
	Up
	Left
	OK
	Right
	Down
	Back
	:≡
	:≡
	Play
	Power
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	D.Menu / Top
	Menu / Home
	Picture / Format
	Up
	Left
	OK
	Right
	Down
	Back / Return
	Smart / List
	Setup / OPT /
	Play / Slow

Original	Substitut
	Pause
	I<
	Stop
	Eject
	>I
	<<
	>>
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Subtitle
	Pause / Step / Freeze
	I<< / Preset-
	Stop / Hold
	Eject / Surround
	>>I / Preset+
	<< / Tune-
	>> / Tune+
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Subtitle / EQ



