





















| Original | Substitut |
|---|-----------|
|  | Mute |
|  | Power |
|  | 1 |
|  | 2 |
|  | 3 |
|  | 4 |
|  | 5 |
|  | 6 |
|  | 7 |
|  | 8 |
|  | 9 |
|  | APP |
|  | APP |
|  | 0 |
|  | Back |
|  | L- |
|  | L+ |

| Original | Substitut |
|---|-----------------------|
|  | Mute / Dimmer |
|  | Power |
|  | 1 |
|  | 2 |
|  | 3 |
|  | 4 |
|  | 5 |
|  | 6 |
|  | 7 |
|  | 8 |
|  | 9 |
|  | Shift + Green / APP / |
|  | Display / Media |
|  | 0 |
|  | Back / Return |
|  | I<< / Preset- |
|  | >>I / Preset+ |

| Original | Substitut |
|---|-------------|
|  | Menu |
|  | Up |
|  | Exit |
|  | Left |
|  | OK |
|  | Right |
|  | CH+ / Page+ |
|  | Down |
|  | Vol+ |
|  | CH- / Page- |
|  | Vol- |
|  | Info |
|  | List |
|  | EPG |
|  | Red |
|  | Green |
|  | Yellow |

| Original | Substitut |
|---|---------------------------|
|  | Menu / Home |
|  | Up |
|  | Exit / Cancel / Clear |
|  | Left |
|  | OK |
|  | Right |
|  | CH+ / Page+ |
|  | Down |
|  | Vol+ |
|  | CH- / Page- |
|  | Vol- |
|  | Info / Angle |
|  | Smart / List |
|  | Guide / EPG / -/- |
|  | Red / Netflix / Search |
|  | Green / APP / Repeat |
|  | Yellow / YouTube / Repeat |



