



Original	Substitut
	Source AV / Input / RDS
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Eject / Surround
	0
	Guide / EPG / -/-
	Menu / Home
	Exit / Cancel / Clear
	Up

Original	Substitut
	Left
	OK
	Right
	Down
	Setup / OPT /
	Back / Return
	Vol+
	Info / Angle
	CH+ / Page+
	Vol-
	Mute / Dimmer
	CH- / Page-
	Text / Goto
	Subtitle / EQ
	Smart / List
	TV/Radio /
	Red / Netflix / Search





Original	Substitut	Original	Substitut
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue/Lang	 Blue / Prime Video / Random		

