



	Original	Substitut		Original	Substitut
	Power	Power		Exit	Exit
	Mute	Mute		Up	Up
	1	1		Down	Down
	2	2		Right	Right
	3	3		Left	Left
	4	4		Ok	Ok
	5	5		Vol+	Vol +
	6	6		Vol-	Vol -
	7	7		Sound	Shift + Dual
	8	8		Pic	Shift + Format
	9	9		Ch+	Ch +
	0	0		Ch-	Ch -
	Audio	Dual		Sleep	Sleep
	Recall	Back		Aspect	Format
	Tv Menu	Menu		Freeze	Eject
	Source	AV		Tv/Radio	TV/R
	ChList	List		Text	Text





Original		Substitut		Original		Substitut	
	Epg		Guide		I<<		I<<
	Fav		Pre Ch		>>I		>>I
	Info		Info		Play		Play
	Red		Red		Pause		Pause
	Green		Green		Stop		Stop
	Yellow		Yellow		Rec/Rep		Rec
	Blue		Blue				
	Reveal		Media				
	Hold		D. Menu				
	Index		Shift + Info				
	Subpage		Shift + AV				
	List		Smart				
	Mix		Options				
	Subtitle		Subt				
	Size		3D				
	<<		<<				
	>>		>>				

