







































































































Original	Substitut	Original	Substitut
 Power	 Power	 9	 9
 CH.List	 List	 0	 0
 Tv/Radio	 TV/R	 Info	 Info
 FAV	 Pre Ch	 Recall	 Back
 Sleep	 Sleep	 Freeze	 Pause
 Input	 AV	 Guide	 Guide
 Sound	 Shift + Dual	 I/II/Audio Lang	 Dual
 Picture	 Shift + Format	 Vol+	 Vol +
 Aspect	 3D	 Vol-	 Vol -
 1	 1	 Mute	 Mute
 2	 2	 Prog+	 Ch +
 3	 3	 Prog/Page-	 Ch -
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok





Original	Substitut	Original	Substitut
 Menu	 Menu		
 Exit	 Exit		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Index	 Shift + Info		
 Hold	 Options		
 Text	 Text		
 Size	 Format		
 Subtitle	 Subt		
 Mix	 Media		
 Reveal	 Smart		
 Cancel	 Eject		
 Time	 Shift + AV		
 Subpage	 D. Menu		

