



Original		Substitut		Original		Substitut	
	Power		Power		Exit		Exit
	[≡i]/Info		Info		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		Enter		Ok
	5		5		CH+		Ch +
	6		6		CH-		Ch -
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		Mute		Mute
	0		0		List		List
	[≡?]/Source		AV		Sleep		Sleep
	O)/II/Audio		Dual		EPG		Guide
	Menu		Menu		Red		Pre Ch
	[≡♦]/[+]		3D		Green		Red
	Recall		Back		Green		Green





	Original	Substitut	Original	Substitut
	Yellow			Yellow
	Blue			Blue
	<<			<<
	>>			>>
	<<			<<
	>>			>>
	Play			Play
	Pause			Pause
	Stop			Stop
	Rec			Rec
	[≡]			Text
	[≡+]/Still			Format
	[≡o]/Subtitle			Subt
	Radio			TV/R
	[≡x]			Options
	DMP			Smart
	Index			Media

