























































































































Original	Substitut	Original	Substitut
 Power	 Power	 Menu	 Menu
 Tv	 TV/R	 Return	 Back
 1	 1	 Info	 Info
 2	 2	 Exit	 Exit
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 Enter	 Eject
 8	 8	 Red	 Red
 9	 9	 Green	 Green
 0	 0	 Yellow	 Yellow
 Enter	 Ok	 Blue	 Blue
 PRE-CH	 Pre Ch	 Vol +	 Vol +
 CH LIST	 List	 Vol -	 Vol -
 FAV CH	 Shift + Pre Ch	 Mute	 Mute
 Tools	 Options	 Source	 AV

Original	Substitut	Original	Substitut
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 DVD	 SAT	 AUX
 PLAY MODE	 REC MODE	 >>>	 >>>
 II	 ■	 <<<	 <<<
 <<<	 SOUND	 AD	 SETTINGS
 DISC NAV	 DUAL	 SUBT	 OPT
 LIST	 SEARCH	 PICTURE	 ECO
 PROG	 TV/R	 FORMAT	 3D
 SLEEP	 REPEAT	 ZOOM	 TIMER
 E-MANUAL	 TEXT	 ▲	 AV
 D.MENU	 MENU	 INFO	
 OK	 ▲	 ►	
 ◀	 ▼	 ◀	
 EXIT	 BACK	 HOME	
 +	 SMART	 APP	
 -	 MEDIA	 CH	
 1	 2	 3	
 4	 5	 6	
 7	 8	 9	
 GUIDE	 0	 FAV	
 A	 PRE-CH		
 B			
 C			
 D			
			
www.mandis.tv			





Original	Substitut	Original	Substitut
 PR+	 Ch +		
 PR-	 Ch -		
 TTX/MIX	 Text		
 Media.P	 Media		
 P.Size	 Format		
 Dual	 Dual		
 Guide	 Guide		
 Subt	 Subt		
 <<	 <<		
 Pause	 Pause		
 >>	 >>		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		

