





Original	Substitut
Power	Power
Tv/Rad	TV/R
Search	Shift + TV/R
Live Zoom	Eject
*	Menu
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Guide	Guide

Original	Substitut
Q.View	D. Menu
FAV/Quick	Pre Ch
Info	Info
Vol+	Vol +
Vol-	Vol -
Mute	Mute
P+	Ch +
P-	Ch -
Netflix	Shift + Media
Home	Smart
Amazon	Media
Text	Text
Back	Back
T.Opt/Magic Link	Options
Exit	Exit
Up	Up
Down	Down





Original	Substitut	Original	Substitut
	Right		Right
	Left		Left
	OK		Ok
	AD/*		Subt
	Rec		Rec
	Stop		Stop
	<<		<<
	Play		Play
	Pause		Pause
	>>		>>
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

