











































































































Original	Substitut	Original	Substitut
 Power	 Power	 >>I	 >>I
 Source	 AV	 <<	 <<
 Open/Close	 Eject	 >>	 >>
 Sleep	 Sleep	 Stop	 Stop
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 Vol+	 Vol +
 4	 4	 Vol-	 Vol -
 5	 5	 Mute	 Mute
 6	 6	 Repeat	 Text
 7	 7	 Tuning+	 Ch +
 8	 8	 Tuning-	 Ch -
 9	 9	 Disc Menu	 D. Menu
 0	 0	 Menu	 Menu
 Dolby PL	 Dual	 Title Menu	 TV/R
 DSP/EQ	 Guide	 Tools	 Options
 I<<	 I<<	 Info	 Info





Original	Substitut
 Power	 Power
 Function Tv	 AV
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 <<	 <<
 >>	 >>
 Stop	 Stop
 Play	 Play

Original	Substitut
 Pause	 Pause
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Tools	 Options
 Info	 Info
 Return	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Red	 Red



