



| Original    | Substitut                |
|-------------|--------------------------|
| Power       | Power                    |
| Power Tv    | Shift + Power            |
| DVD         | Shift + 2                |
| HDD         | Shift + 7                |
| Open/Close  | Eject / Surround         |
| Av/Input Tv | Shift + AV / Input / RDS |
| 1           | 1                        |
| 2           | 2                        |
| 3           | 3                        |
| PR/CH+ Tv   | Shift + CH+ /            |
| 4           | 4                        |
| 5           | 5                        |
| 6           | 6                        |
| PR/CH- Tv   | Shift + CH- /            |
| 7           | 7                        |
| 8           | 8                        |
| 9           | 9                        |

| Original   | Substitut             |
|------------|-----------------------|
| Vol+ Tv    | Vol+                  |
| Dubbing    | Setup / OPT /         |
| 0          | 0                     |
| AV/Input   | AV / Input / RDS      |
| Vol- Tv    | Vol-                  |
| << Scan    | << / Tune-            |
| Scan >>    | >> / Tune+            |
| I<< Skip   | I<< / Preset-         |
| Skip >>I   | >>I / Preset+         |
| Pause/Step | Pause / Step / Freeze |
| Play       | Play / Slow           |
| Stop       | Stop / Hold           |
| Home       | Menu / Home           |
| Up         | Up                    |
| PR/CH+     | CH+ / Page+           |
| Menu/List  | D.Menu / Top          |
| Menu/List  | Smart / List          |





| Original  | Substitut              |
|-----------|------------------------|
| Left      | Left                   |
| Enter     | OK                     |
| Right     | Right                  |
| Display   | Display / Media        |
| Down      | Down                   |
| PR/CH-    | CH- / Page-            |
| Return    | Back / Return          |
| Timeshift | Info / Angle           |
| Audio     | Audio / Lang I/II      |
| Subtitle  | Subtitle / EQ          |
| CHP.ADD   | Text / Goto            |
| Rec       | Rec / Rec Mode         |
| Rec Mode  | Shift + Rec / Rec Mode |
| Title     | Sound / Title          |
| Thumbnail | Picture / Format       |
| Zoom      | Zoom / Size            |
| Marker    | Fav / Marker / PC      |

| Original | Substitut                 |
|----------|---------------------------|
| Search   | Red / Netflix / Search    |
| Clear    | Exit / Cancel / Clear     |
| Repeat   | Green / APP / Repeat      |
| A-B      | Yellow / YouTube / Repeat |
| Tv/DVD   | TV/Radio /                |
| *        | Guide / EPG / -/--        |

