



Original	Substitut	Original	Substitut
	Power		Power
	Mode DVB		Setup / OPT /
	Direct TV Rec		Rec / Rec Mode
	Guide		Guide / EPG / -/--
	Up		Up
	TV / AV		AV / Input / RDS
	Left		Left
	OK		OK
	Right		Right
	Menu		Menu / Home
	Down		Down
	Exit		Exit / Cancel / Clear
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Text		Text / Goto

Original	Substitut	Original	Substitut
	STTL / FP		Subtitle / EQ
	Index		Smart / List
	Hold		Shift + Stop /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	C		Fav / Marker / PC
	0 / VCR		0
	i		Info / Angle
	CH +		CH+ / Page+
	Vol +		Vol+





