







Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Pre Ch
	Recall		Back
	Lang		Dual
	Time Shift		Smart
	Tv/Radio		TV/R

Original	Substitut	Original	Substitut
	Dev.List		List
	EPG		Guide
	Subtitle		Subt
	Text		Text
	Auto		Options
	Menu		Menu
	Zoom		Eject
	Info		Info
	Exit		Exit
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Vol+		Vol +





	Original	Substitut	Original	Substitut
	Vol-	Vol -		
	Filelist	Media		
	Rec	Rec		
	Stop	Stop		
	Play	Play		
	Pause	Pause		
	<<	<<		
	>>	>>		
	I<<	I<<		
	>>I	>>I		
	Red/FAV/Daily	Red		
	Green/DEL/Weekl	Green		
	Yellow/Movie/P.Inf	Yellow		
	Blue/Lock/Timer	Blue		

