







































	Original	Substitut		Original	Substitut
	Power	 Power		Eco	 Smart / List
	RGB	 TV/Radio /			
	Video	 4			
	Still	 Pause / Step / Freeze			
	Sleep	 Sleep / Timer			
	Blank	 Back / Return			
	Menu	 Menu / Home			
	Up	 Up			
	Ratio	 Picture / Format			
	Left	 Left			
	OK	 OK			
	Right	 Right			
	Auto	 Display / Media			
	Down	 Down			
	Zoom	 Zoom / Size			
	Info	 Info / Angle			
	Keystone	 AV / Input / RDS			

