



Original	Substitut	Original	Substitut
	Power		Power
	Source		AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	TTX/MIX		Text
	PRE-CH		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	CH List		List
	P+		Ch +
	P-		Ch -
	Menu		Menu
	Smart Hub		Smart
	Guide		Guide
	Tools		Options
	Info		Info
	Return		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Red		Red
	Green		Green





Original	Substitut	Original	Substitut
Yellow	Yellow		
Blue	Blue		
Search	TV/R		
Status	Media		
AD/Subt.	Subt		
E-Manual	D. Menu		
Recommend	Format		
3D	3D		
<<	<<		
I<<	I<<		
Pause	Pause		
>>	>>		
>>I	>>I		
Rec	Rec		
Play	Play		
Stop	Stop		

