


































































































Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute / Dimmer
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	Rec		Rec / Rec Mode
	<<		<< / Tune-
	l<<		l<< / Preset-
	>>l		>>l / Preset+
	>>		>> / Tune+
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info / Angle
	EPG		Guide / EPG / -/-
	≡		Menu / Home
	Source		AV / Input / RDS
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		OK
	Exit		Exit / Cancel / Clear
	Smart		Smart / List
	←		Back / Return
	Vol+		Vol+
	P+		CH+ / Page+





Original	Substitut
	 Vol-
	 Shift +  Menu /
	 CH- / Page-
	 Shift +  Red / Netflix /
	 Shift +  Yellow / YouTube /
	 Red / Netflix /  Search
	 Green / APP / Repeat
	 Yellow / YouTube /  Repeat
	 Blue / Prime Video /  Random
	 Audio / Lang I/II
	 Text / Goto
	 Subtitle / EQ

Original	Substitut

