







































































Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute
	TV / AV		AV
	Menu		Menu
	Sleep		Sleep
	Up / PR+		Up
	Up / PR+		Ch +
	Down / PR-		Down
	Down / PR-		Ch -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Left / Vol-		Left
	Left / Vol-		Vol -
	OK		Ok
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	APC		I<<<
	ASC		<<<
	ARC		>>>
	PIP		Smart
	Review		Info
	MTS		Dual
	Multi PIP		Format
	Multimedia		Media
	Red / PIP CH+		Red
	Green / PIP CH-		Green





Original	Substitut
Yellow / PIP SWAP	Yellow
Blue / PIP Input	Blue
Text	Text
Mode	Options
Size / PIP Size	Eject
Mix	TV/R
Sub Page	Subt
Index	Shift + Info
Reveal	D. Menu
Hold / PIP Still	Stop
Update / PIP Position	Guide

Original	Substitut

