



Original	Substitut	Original	Substitut
 Power	 Power	 7	 7
 Mute	 Mute	 8	 8
 Audio	 Dual	 9	 9
 TV / STB	 Shift + TV/R	 0	 0
 TV / R	 TV/R	 PGUP	 Vol +
 Sleep	 Sleep	 PGDN	 Vol -
 SUB	 Subt	 SAT	 Shift + AV
 TXT	 Text	 FAV +	 Ch +
 Multi	 Smart	 FAV -	 Ch -
 P / N	 Shift + 1	 EPG	 Guide
 Recall	 Pre Ch	 Fav	 Shift + Pre Ch
 1	 1	 Up / CH+	 Up
 2	 2	 Right / Vol+	 Right
 3	 3	 Down / CH-	 Down
 4	 4	 Left / Vol-	 Left
 5	 5	 OK	 Ok
 6	 6	 Menu	 Menu





Original		Substitut		Original		Substitut	
	Exit		Exit		Stop		Stop
	Red		Red		Rec		Rec
	Green		Green		<<		<<
	Yellow		Yellow		>>		>>
	Blue		Blue		Play / Pause		Play
	Pause		Pause		> <	 + 	Shift + Pause
	Zoom		Eject		<<		<<
	Edit		Format		>>		>>
	Info		Info				
	USB		AV				
	MP3		Media				
	JPEG	 + 	Shift + Media				
	PVR List		List				
	PIP	 + 	Shift + Ok				
	A - B		Back				
	T.S.	 + 	Shift + 2				
	Goto		Options				

