







Original	Substitut	Original	Substitut
	Power		Power
	Open / Close		Eject / Surround
	Sleep		Sleep / Timer
	Dimmer /		TV/Radio /
	DVD		Shift + 2
	Tuner		Shift + 6
	Aux		Shift + 7
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Remain		D.Menu / Top

Original	Substitut	Original	Substitut
	0		0
	Cancel		Exit / Cancel / Clear
	I<<		I<< / Preset-
	Stop		Stop / Hold
	Play / Pause		Play / Slow
	>>I		>>I / Preset+
	Dolby PL II Mode		Smart / List
	Volume +		Vol+
	Tuning + / CH +		CH+ / Page+
	Dolby PL II Effect		Display / Media
	Volume -		Vol-
	Tuning - / CH -		CH- / Page-
	Menu		Menu / Home
	Info.		Info / Angle
	Sub Title		Subtitle / EQ
	Up		Up
	Audio		Audio / Lang I/II





















Original	Substitut
	 Left
	 OK
	 Right
	 Back / Return
	 Down
	 Mute / Dimmer
	 Pause / Step / Freeze
	 Green / APP / Repeat
	 Picture / Format
	 Text / Goto
	 Zoom / Size
	 Shift + Sound / Title
	 AV / Input / RDS
	 Sound / Title
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Red / Netflix / Search

Original	Substitut
	 Shift + Subtitle / EQ





Original	Substitut	Original	Substitut
	Power		Power
	Sleep		Sleep / Timer
	Dimmer /		TV/Radio /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Volume +		Vol+
	Tuning + / CH +		CH+ / Page+
	Volume -		Vol-
	Tuning - / CH -		CH- / Page-

Original	Substitut	Original	Substitut
	Menu		Menu / Home
	Info		Info / Angle
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Mute		Mute / Dimmer

