







































































Original	Substitut	Original	Substitut
 POWER	 Power	 6	 6
 TELETEXT	 Text	 7	 7
 Index	 Play	 8	 8
 Clock / Subpage	 Pause	 9	 9
 Hold	 Stop	 0	 0
 Reveal	 Rec	 MUTE	 Mute
 Cancel	 <<	 RTN.	 Back
 Size	 >>	 CH+	 Ch +
 RED	 Red	 CH-	 Ch -
 GREEN	 Green	 VOL+	 Vol +
 YELLOW	 Yellow	 VOL-	 Vol -
 BLUE	 Blue	 ARC	 Smart
 1	 1	 APC	 Media
 2	 2	 UP	 Up
 3	 3	 LEFT	 Left
 4	 4	 OK	 Ok
 5	 5	 RIGHT	 Right





Original	Substitut
DOWN	Down
MENU	Menu
EXIT	Exit
TV	+ Shift + Red
PC / HD	+ Shift + Green
VIDEO	+ Shift + Yellow
SCART	+ Shift + Blue
SOUND	Dual
SUB-TITLE	Subt
GUIDE	Guide
SLEEP	Sleep
PIP ON/OFF	+ Shift + Ok
PIP SWAP	+ Shift + Left
PIP SWAP	+ Shift + Right
PIP SOURCE UP	+ Shift + Up
PIP SOURCE	+ Shift + Down
PIP SIZE	+ Shift + Media

Original	Substitut
PIP POSITION	+ Shift + Smart

