





































| Original    | Substitut   | Original   | Substitut   |
|-------------|---|------------|---|
| On/Off      |  Power   | OK Enter   |  Ok    |
| Mute        |  Mute    | Menu Right |  Right |
| Update      |  Play    | Menu Off   |  Exit  |
| Reveal      |  Pause   | Menu Down  |  Down  |
| Txt Stop    |  Stop    | Back       |  Back  |
| Info        |  Rec     | Volume+    |  Vol + |
| Subt.List   |  Subt    | Chan.Up    |  Ch +  |
| Sleep Timer |  Sleep   | Volume-    |  Vol - |
| Return TV   |  TV/R    | Menu audio |  Dual  |
| Menu video  |  D. Menu | Chan.Down  |  Ch -  |
| Text        |  Text   | 1          |  1    |
| Txt Expand  |  Eject | 2          |  2   |
| TV/AV       |  AV    | 3          |  3   |
| Menu        |  Menu  | 4          |  4   |
| Menu Up     |  Up    | 5          |  5   |
| Display     |  Info  | 6          |  6   |
| Menu Left   |  Left  | 7          |  7   |



| Original      | Substitut  | Original       | Substitut  |
|---------------|--|----------------|--|
| 8             |  8  | Nicam/Mono     |  +  Shift + Green  |
| 9             |  9  | Level L        |  +  Shift + Yellow |
| Guide -/-- 1. |  GUIDE  | Level R/Woofer |  +  Shift + Blue   |
| 0/10          |  0  |                |  |
| 2.Fav P/C 2.  |  PRE-CH   |                |  |
| Red           |  A  |                |  |
| Green         |  B  |                |  |
| Yellow        |  C  |                |  |
| Blue          |  D  |                |  |
| Audio-        |  <<   |                |  |
| Audio+        |  >>  |                |  |
| Tone-         |  +  Shift + Stop |                |  |
| Mix Scan      |  LIST   |                |  |
| Color+ P.Std  |  FORMAT   |                |  |
| Color- S.Std  |  +  Shift + Dual |                |  |
| AV 2          |  +  Shift + AV   |                |  |
| Surround      |  +  Shift + Red  |                |  |

