















































Original	Substitut
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Display	 Info
 Recall	 Back
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Sleep	 Sleep

Original	Substitut
 Menu	 Menu
 Exit	 Exit
 Text	 Text
 FAV	 Pre Ch
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Source	 AV
 EPG	 Guide
 CH+	 Ch +
 CH-	 Ch -
 Red	 Red
 Green	 Green





Original		Substitut		Original		Substitut	
	Yellow		Yellow		Index		List
	Blue		Blue		Home		Smart
	Play		Play				
	Pause		Pause				
	<<		<<				
	>>		>>				
	Rec		Rec				
	Stop		Stop				
	I<<		I<<				
	>>I		>>I				
	Tv/Radio		TV/R				
	Subpage		Eject				
	Subtitle		Subt				
	Reveal		3D				
	Audio		Dual				
	Size		Format				
	Hold		Options				

