



































Original	Substitut
	Power
	Mute
	PP
	I - II
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	P<P
	--
	M/Menu













Original	Substitut
	Power
	Mute / Dimmer
	Back / Return
	Audio / Lang I/II
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Fav / Marker / PC
	Guide / EPG / -/--
	Menu / Home

Original	Substitut
	i
	PR+
	PR-
	Up
	Down
	Right
	Left
	Vol+
	Vol-
	Red / Sound
	Green / Picture
	Yellow / Feature
	Blue / Install
	TV
	AV
	[=]
	[=o]

Original	Substitut
	Info / Angle
	CH+ / Page+
	CH- / Page-
	Up
	Down
	Right
	Left
	Vol+
	Vol-
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	TV/Radio /
	AV / Input / RDS
	Text / Goto
	Subtitle / EQ





Original	Substitit
 [=+]	 Picture / Format
 [=?]	 Eject / Surround
 [=i]	 Smart / List
 [=x]	 Display / Media
 [=♦]	 Zoom / Size
 [=.]	 Setup / OPT /

Original	Substitit

