



Original	Substitut
 Power	 Power
 Mute	 Mute / Dimmer
 Freeze	 Pause / Step / Freeze
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Info	 Info / Angle
 0	 0
 Previous	 Back / Return
 Red	 Red / Netflix / Search
 Blue	 Blue / Prime Video / Random

Original	Substitut
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Aspect	 Shift + Picture / Format
 I/II	 Audio / Lang I/II
 Menu	 Menu / Home
 Source	 AV / Input / RDS
 TV	 Exit / Cancel / Clear
 TV	 Smart / List
 Up	 Up
 PR+	 CH+ / Page+
 Left	 Left
 OK	 OK
 Right	 Right
 Vol+	 Vol+
 Down	 Down
 PR-	 CH- / Page-
 Vol-	 Vol-





Original	Substitut
 Picture	 Picture / Format
 Sound	 Sound / Title
 Text	 Text / Goto
 Sleep	 Sleep / Timer
 Zoom	 Zoom / Size
 Index	 Eject / Surround
 Hold	 Stop / Hold
 Cancel	 Shift + Exit / Cancel / Clear
 Sub.code	 Subtitle / EQ
 Reveal	 TV/Radio /
 Mix	 Setup / OPT /

Original	Substitut

