















































































Original	Substitut	Original	Substitut
 Power	 Power	 Vol+	 Vol+
 Energy Saving	 Sleep / Timer	 FAV/Mark/Char/Nu	 Fav / Marker / PC
 AV Mode	 Picture / Format	 P+	 CH+ / Page+
 Input	 AV / Input / RDS	 Vol-	 Vol-
 Tv/Rad	 TV/Radio /	 3D	 Zoom / Size
 1	 1	 Mute/Delete	 Mute / Dimmer
 2	 2	 P-	 CH- / Page-
 3	 3	 Menu	 Menu / Home
 4	 4	 NetCast	 Sound / Title
 5	 5	 Q.Menu	 D.Menu / Top
 6	 6	 Up	 Up
 7	 7	 Left	 Left
 8	 8	 OK	 OK
 9	 9	 Right	 Right
 List	 Smart / List	 Down	 Down
 0	 0	 Exit	 Exit / Cancel / Clear
 Q.Vlew	 Setup / OPT /	 Back	 Back / Return





Original	Substitut	
GUIDE	Guide	 Guide / EPG / -/--
	Red	 Red / Netflix / Search
	Green	 Green / APP / Repeat
	Yellow	 Yellow / YouTube / Repeat
L/R SELECT	Blue/L/R/Select	 Blue / Prime Video / Random
	Text	 Text / Goto
T.OPT	T.Opt	 Shift + Setup / OPT / Tools
SUBTITLE	Subtitle	 Subtitle / EQ
	Stop	 Stop / Hold
	Play	 Play / Slow
	Pause	 Pause / Step / Freeze
	<<	 << / Tune-
	>>	 >> / Tune+
	Simplink	 Display / Media
	Info	 Info / Angle
AD	AD	 Audio / Lang I/II
APP/*	APP/*	 Shift + Green / APP / Repeat

Original	Substitut

