







































































Original		Substitut		Original		Substitut	
	Power		Power		0		0
	Open/Close		Eject / Surround		Title		Shift + Sound / Title
	Home		Shift + Menu /		Marker		Fav / Marker / PC
	FM/AM		Shift + 6		Search		Red / Netflix / Search
	AV		AV / Input / RDS		Zoom		Zoom / Size
	PIP		Picture / Format		Audio/Mo./St.		Audio / Lang I/II
	1		1		Sound		Sound / Title
	2		2		XTS Pro		Shift + Audio / Lang I/II
	3		3		Level/Delay		Smart / List
	Test Tone		Text / Goto		Menu/List		Menu / Home
	4		4		PR/Preset+		CH+ / Page+
	5		5		Up		Up
	6		6		Setup		Setup / OPT /
	[...]/Subtitle		Subtitle / EQ		Left/Tun-		Left
	7		7		Memory/Enter		OK
	8		8		Right/Tun+		Right
	9		9		Display		Display / Media





Original	Substitut
	CH- / Page-
	Down
	Back / Return
	I<< / Preset-
	>>I / Preset+
	Vol+
	<< / Tune-
	>> / Tune+
	Vol-
	Pause / Step / Freeze
	Play / Slow
	Stop / Hold
	Rec / Rec Mode
	Shift + Rec / Rec Mode
	Sleep / Timer
	Mute / Dimmer
	Blue / Prime Video / Random

Original	Substitut
	Shift + Fav / Marker / PC
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Shift + Guide / EPG / -/--
	Info / Angle
	Guide / EPG / -/--
	Exit / Cancel / Clear
	Shift + AV / Input / RDS
	D.Menu / Top
	Shift + Smart / List
	TV/Radio /

