



























































Original	Substitut
 Power	 Power
 Setup	 Setup / OPT /
 Digest	 Smart / List
 Lang	 Shift + Audio / Lang I/II
 Display	 Display / Media
 1	 1
 2	 2
 3	 3
 Zoom	 Zoom / Size
 4	 4
 5	 5
 6	 6
 A-B Repeat	 Yellow / YouTube / Repeat
 7	 7
 8	 8
 9	 9
 1/All Repeat	 Green / APP / Repeat

Original	Substitut
 0	 0
 +10	 Guide / EPG / -/-
 Clear	 Exit / Cancel / Clear
 Play	 Play / Slow
 Up	 Up
 Stop	 Stop / Hold
 Left	 Left
 Select	 OK
 Right	 Right
 Pause/Step	 Pause / Step / Freeze
 Down	 Down
 Slow	 Shift + Play /
 F.BWD	 << / Tune-
 F.FWD	 >> / Tune+
 Prev.	 I<< / Preset-
 Next	 >>I / Preset+
 Subtitle	 Subtitle / EQ





Original	Substitut	Original	Substitut
 ANGLE	Angle	 ANGLE INFO	Info / Angle
 AUDIO	Audio	 LANG I/II AUDIO	Audio / Lang I/II
 + VOLUME	Volume+	 + VOL	Vol+
 PROGRAM	Program	 SHIFT +  PROGRAM TV/RADIO	Shift + TV/Radio / Program
 MENU/PBC	Menu/PBC	 HOME MENU	Menu / Home
 TITLE/RET.	Title/Ret.	 TITLE SOUND	Sound / Title
 - VOLUME	Volume-	 - VOL	Vol-
 SEARCH	Search	 NETFLIX SEARCH	Red / Netflix / Search
 TV SYS	Tv Sys	 PROGRAM TV/RADIO	TV/Radio /
 TVMODE	Tv Mode	 PC FAV MARKER	Fav / Marker / PC
 MUTE	Mute	 DIMMER MUTE	Mute / Dimmer

Original	Substitut	Original	Substitut

