











































































































Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	FAV		Fav / Marker / PC
	0		0
	List		Shift + Smart / List
	Vol+		Vol+
	TV		TV/Radio /
	P+		CH+ / Page+
	Vol-		Vol-
	Smart		Smart / List
	P-		CH- / Page-
	Home		Shift + Menu /
	Up		Up
	=		Menu / Home
	Left		Left
	OK		OK
	Right		Right
	←		Back / Return
	Down		Down
	Source		AV / Input / RDS
	Exit		Exit / Cancel / Clear
	Zoom		Zoom / Size
	*		D.Menu / Top
	Info		Info / Angle
	EPG		Guide / EPG / -/-





Original	Substitut	Original	Substitut
 Lang/AD	 Audio / Lang I/II	 YouTube	 +  Shift + Yellow / YouTube /
 USB	 +  Shift + 8		
 Subt.	 Subtitle / EQ		
 Text	 Text / Goto		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 <<<	 <<< / Tune-		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 >>>	 >>> / Tune+		
 I<<	 I<< / Preset-		
 Stop	 Stop / Hold		
 >I	 >>I / Preset+		
 Rec	 Rec / Rec Mode		
 Netflix	 +  Shift + Red / Netflix / Search		

