







































































Original	Substitut	Original	Substitut
 Power	 Power	 P.Mode	 Picture / Format
 1	 1	 Text	 Text / Goto
 2	 2	 CH+	 CH+ / Page+
 3	 3	 CH+	 Up
 Red	 Red / Netflix / Search	 Vol-	 Vol-
 4	 4	 Vol-	 Left
 5	 5	 Menu	 Menu / Home
 6	 6	 Vol+	 Vol+
 Green	 Green / APP / Repeat	 Vol+	 Right
 7	 7	 CH-	 Down
 8	 8	 CH-	 CH- / Page-
 9	 9	 S.Mode	 Sound / Title
 Yellow	 Yellow / YouTube / Repeat	 Mute	 Mute / Dimmer
 Recall	 Back / Return	 Zoom / Sub	 Zoom / Size
 0	 0	 Still	 Pause / Step / Freeze
 Display	 Display / Media	 Lang	 Audio / Lang I/II
 Blue	 Blue / Prime Video / Random	 Video / Index	 Info / Angle

Original	Substitut	Original	Substitut
 P.Mode	 Picture / Format	 Picture / Format	 Picture / Format
 Text	 Text / Goto	 Text / Goto	 Text / Goto
 CH+	 CH+ / Page+	 CH+ / Page+	 CH+ / Page+
 CH+	 Up	 Up	 Up
 Vol-	 Vol-	 Vol-	 Vol-
 Vol-	 Left	 Left	 Left
 Menu	 Menu / Home	 Menu / Home	 Menu / Home
 Vol+	 Vol+	 Vol+	 Vol+
 Vol+	 Right	 Right	 Right
 CH-	 Down	 Down	 Down
 CH-	 CH- / Page-	 CH- / Page-	 CH- / Page-
 S.Mode	 Sound / Title	 Sound / Title	 Sound / Title
 Mute	 Mute / Dimmer	 Mute / Dimmer	 Mute / Dimmer
 Zoom / Sub	 Zoom / Size	 Zoom / Size	 Zoom / Size
 Still	 Pause / Step / Freeze	 Pause / Step / Freeze	 Pause / Step / Freeze
 Lang	 Audio / Lang I/II	 Audio / Lang I/II	 Audio / Lang I/II
 Video / Index	 Info / Angle	 Info / Angle	 Info / Angle





Original	Substitut	Original	Substitut
 Hold S-Video	S-Video / Hold	 HOLD	Stop / Hold
 Size PC	PC / Size	 PC FAV MARKER	Fav / Marker / PC
 Reveal Source	Source / Reveal	 RDS AV INPUT	AV / Input / RDS
 Cancel YPbPr	YPbPr / Cancel	 CLEAR EXIT	Exit / Cancel / Clear
 Mix Swap	Swap / Mix	 LIST SMART	Smart / List

