




Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute
	Eject		Eject
	Setup		Options
	Angle		Media
	3D		3D
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/10		0
	+10		Guide

Original	Substitut	Original	Substitut
	Return		Back
	Display		Info
	Title/PBC		TV/R
	Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Play		Play
	Play		Ok
	Search		Shift + TV/R
	Mark		Pre Ch
	Program		Sleep
	Zoom		Shift + Eject
	Pause		Pause
	Pause		Rec
	Stop		Stop





Original	Substitut	Original	Substitut
	Vol+		Vol +
	Vol-		Vol -
	>>		>>
	<<<		<<<
	<<<		<<<
	>>>		>>>
	Audio		Dual
	Subtitle		Subt
	Slow		Exit
	Repeat		Text
	A-B	+	Shift + Text
	Intro	+	Shift + Green
	Channel		List
	V-Mode		Smart
	System		D. Menu
	b		Green
	b		Yellow

Original	Substitut
	#
	Blue

