





































































| Original | | Substitut | | Original | | Substitut | |
|---|----------|---|-----------------------|---|-----------|---|-----------------------|
|  | Power |  | Power |  | Index |  | D.Menu / Top |
|  | Mute |  | Mute / Dimmer |  | Reveal |  | Setup / OPT / |
|  | Play |  | Play / Slow |  | Text |  | Text / Goto |
|  | Pause |  | Pause / Step / Freeze |  | AV/Source |  | AV / Input / RDS |
|  | Stop |  | Stop / Hold |  | Menu |  | Menu / Home |
|  | Rec |  | Rec / Rec Mode |  | Up |  | Up |
|  | << |  | << / Tune- |  | i/Info |  | Info / Angle |
|  | >> |  | >> / Tune+ |  | Left |  | Left |
|  | I<< |  | I<< / Preset- |  | OK |  | OK |
|  | >>I |  | >>I / Preset+ |  | Right |  | Right |
|  | S.Mode |  | Sound / Title |  | Exit |  | Exit / Cancel / Clear |
|  | Audio |  | Audio / Lang I/II |  | Down |  | Down |
|  | Subtitle |  | Subtitle / EQ |  | Back |  | Back / Return |
|  | P.Mode |  | Picture / Format |  | Vol+ |  | Vol+ |
|  | Size |  | Zoom / Size |  | Rec List |  | Smart / List |
|  | Sleep |  | Sleep / Timer |  | CH+ |  | CH+ / Page+ |
|  | Tv/Radio |  | TV/Radio / |  | Vol- |  | Vol- |





| Original | Substitut |
|----------|---------------------------|
| ATV | Display / Media |
| CH- | CH- / Page- |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| Tv Guide | Guide / EPG / -/-- |
| 0 | 0 |
| FAV | Fav / Marker / PC |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |

| Original | Substitut |
|---------------|-----------------------------|
| Blue | Blue / Prime Video / Random |
| Power/Display | Shift + Power |
| Hold | Shift + Stop / |
| Aspect | Shift + Picture / Format |
| USB | Shift + 8 |

